

# AVIVA™ ELECTRIC BIKES

How to Install and care for:  
AVIVA™ lithium-Ion Battery

Aviva™ - For A New Way Of Life

Push tab down on seat and bend forward.  
Slide down the battery in the channel attached to the frame.  
**Make sure that there are no keys in the battery!**





Take key and place in bottom lock and turn the key clockwise to lock the battery to the bike and take the key out.

Next, take the key and place it in the top lock switch and turn it to the on position.



Finally place the seat back in the locked and level position and you are finished.



# AVIVA™ Battery Care

1. slide the charging plug cover on battery over and insert the plug to charge.
2. Charging should take 3-4 hours. Don't overcharge to insure the long life of battery.
3. Your battery should power assist you for 25-40 miles depending on conditions.
4. Aviva Lithium Ion Batteries should be charged every 60 days, if possible, to prolong the life of the battery.



# AVIVA™ Contact Information :

- ▶ Email: [sales@avivabikes.com](mailto:sales@avivabikes.com)
- ▶ Phone : 401-523-9199